

Hoe stel ik detectie in op een thermische camera met IVS

1. Ga naar smartplan en kies de sensor waar u detectie op wil doen
2. Zet IVS aan het lampje word nu oranje
3. Druk op het groene plusje en kies intrusion of tripwire
4. Teken het detectie gebied
5. Teken een minimale grote. Alles wat kleiner is dan dit vak wordt niet gedetecteerd. Dit verminderd het aantal valse alarmen
6. Zet eventueel het object filter aan en filter op mens en/of voertuig



Camera  
Network  
Peripheral  
Smart Thermal  
Smart Plan  
IVS  
Fire Warning  
Call Detection  
Smoking Detection  
Hot Trace  
Pic In Pic  
Event  
Storage  
System  
Information

Rule Config | Global Setup

Channel: 2

No.	Name	Rule Type
1	IVS-1	Intrusion

Parameter Setup

Period: Setting

Duration: 1 s (1~600)

Action:  Appears  Cross

Direction: Enter&Exit

Object filter

Effective object:  Human  Motor Vehicle

Record:  Record Delay: 10 s (10~300)

Relay-out:  Alarm Delay: 10 s (3~300)

Send Email:  Audio Linkage:  Play Count: 5 (1~15) File: alarm1.pcr

Warning Light: Mode: Normally o Duration: 30 s (5~30) Period: Setting

Snapshot:  Snapshot: 1 2

Draw Rule 4

Clear

Target filter:  Max Size 8191 \* 8191  Min Size 436 \* 685

Draw Target

Clear

5

6