INNOVV K7 LED-indicatoren



Remote Control Instruction

Statues	Off	Solid on	Flash quickly (flash 5 times/ second)	Flash slowly (flash twice/ second)	Flash quickly for a long time (flash twice/second)	Flash quickly (flash twice)
23	Not working	Recording	No TF card/ TF card error	Protected video	Accident video, protected video or parking video recorded under specific conditions	Successfully take and save pictures
	Wi-Fi off	Connected	One of cameras disconnected	Connecting		
GPS	GPS off	Connected	-	Connecting		
Firmware Updating	Wi-Fi indicator flashes alternately with recording indicator					
Instruction	of the fu	nction butto	on on remote of	control		